


Cleaning Alcoa® Wheels



LvL ONE®, Polished and Brushed wheels



1.



Rinse with warm water; preferably with a high pressure cleaner.

2.



Pour a quantity of ALclean into a bucket and dilute with 1, 2 or 3 parts of water.

3.



Recommended quantities:

1. for difficult spots
2. for medium pollution
3. for regular use
4. for frequent use

4.



Gently brush ALclean onto the wheel.

5.



Rinse with clean water.
Repeat these steps if needed.

6.



Dry the wheel.

LvL ONE® and Polished wheels

7.




Continue by applying a small amount of ALpolish.

8.



Spread it evenly over the wheel using a moist cloth and polish the wheel.



Repeat steps 7 and 8 section by section to prevent the polish from drying out

Alcoa® Wheels cleaning products

ALclean

- Removes oxidation, disk brake dust, salt spray and general stains
- Suitable for Brushed, LvL ONE® and Mirror Polished finishes

ALpolish

- Restores shine of Mirror Polished and LvL ONE® finishes
- Use after ALclean

ALbrush2

- Rubber edge to avoid damage of the wheel
- 6 cm polyester plucked fibres



For additional information on cleaning and maintenance see page 84 of the Service Manual for Alcoa Wheels.